



Dooly™ installation instructions for all models (Composite) 1997-2003 Polaris Skis.

A ski modification is needed to fit the Woody's® Dooly™ on the Polaris factory installed ski to accommodate an additional mounting stud.

1. Measure 4" from the center of the hole nearest the tip of the ski. Mark this spot as the center of the new hole to be drilled.
2. On this mark bore a hole using a 3/8-drill bit, which may need to be enlarged slightly.
3. Drill through the ski. Some ski's construction may require you to drill through the metal ski saddle.
4. Install Woody's® Dooly™ by following the installation instructions provided..

INTERNATIONAL ENGINEERING & MANUFACTURING, Inc.

6054 N Meridian Road • Hope MI 48628 • 989-689-4911 • www.woodystraction.com • E-mail: woodys@wiem.com
Copyright© 2004, International Engineering & Mfg., Inc. All rights reserved.