



Camoplast / Arctic Cat and Ski-Doo Block Track Studding

Some Artic Cat and Ski-Doo snowmobiles are equipped with a block track, special care needs to be taken when selecting a starting point. The track design will accommodate support plates only in every other outside lug. Before you drill your track, place a support plate in the desired location. If the support plate does not lay flat on the track, move up one bar and try again. The support plate should now fit securely against the track. Use this as your starting point and stud every other bar on the outside.


These Camoplast part #'s will also apply---

690-9830 = 15" x 121" x 1"

690-9831 = 15" x 136" x 1"

690-9837 = 15" x 121" x 1"

690-9838 = 15" x 136" x 1"



Wrong Location



Correct Location