



Technical Tip
S4-06-0003-2

Torque Recommendations for Stud Installation

The torque recommendation for Woody's stud installation is:

Push-Through Studs	180 inch-lbs./15 ft-lbs.
T-Nut & Snap-Off	100-120 inch-lbs./8-10 ft-lbs.
Grand Master Studs	20 ft. - lbs.

These torque recommendations must be sustained to maintain optimum traction and to prevent track damage. After each ride, check the torque of your studs/nuts.