



Tech Tip
T7-09-0006

STUDDING INSTRUCTIONS FOR 19.7", 20" and 24" WIDE TRACKS

Snowmobiles with wide tracks have studding recommendations. They are not automatically provided in our application guide because Woody's does not have a template that will fit the width of these tracks. It is necessary that you contact our Technical Assistance Department for instructions.

These sleds have tracks that are 19.7", 20" or 24" wide. We do recommend studding these tracks. It is necessary to call our tech line for instructions about choosing a stud quantity and how to create the pattern for installing studs. Ask about the correct runner to balance with the stud quantity chosen.

If you are looking for runner replacement part numbers, Woody's does provide runner replacement recommendations for zero quantity studs in this application.

Indicate No when asked, "Do you wish to use studs?" The runner recommendations will be generated for zero stud quantity.

If you already have studs in your track and are looking for the part numbers for the correct runner to install, I use the runner application guide at this link.

http://www.woodystraction.com/catalog/details_product.aspx?id=0406041447432724&cat=4

This application guide will provide all three riding style runner part numbers in addition to the number of studs recommended. Choose the runner that corresponds with the number of studs you have installed.

Thank you for choosing Woody's as your traction and control product.

WARNING Review the snowmobile and track manufacturer's studding recommendations in your owner's manual. You may void your warranty if their recommendations are not followed. You must read and understand these instructions before drilling holes in your track, if you have any questions contact Woody's through the methods listed at the bottom of the page